

# Validation of thermo-mechanical deformation of an in-orbit antenna

Third International Workshop on the Validation of Computational Mechanics Models

Alexander Ihle & Olaf Reichmann



# **Table of Contents**

Part 1: Technical Concept

Part 2: ESPI

Part 3: STANT Thermo-Mechanical Deformation Test and Modeling

Part 4: Conclusion and Outlook








# **Highly Stable Antenna Technologies (STANT)**

- ESA ARTES 5.2 activity
- Ka-band & Q/V-band
- 1 to 19 RF beams, European coverage
- Compact
- High thermo-elastic stability
- High stiffness to mass ratio
- Low heat transfer between S/C and antenna
- Neither reflector coating nor sunshields
- For CFRP <u>&</u> Alu-satellite top decks
- Mass below 10kg
- 1 eigenfrequency > 100Hz
- In-orbit deformation < 20µm RMS.








Gregorian dual reflector configuration




# **STANT Testing**

















# **Electro Specle Pattern Interferometry**


- Optical measurement:
  - Illuminate target with pulsed laser
  - Record back scattered light "Speckle Pattern"
  - Compare with reference beam "PhaseImage"
  - Phase image remains constant as long as geometry between laser, camera and object does not change
- ESPI data analysis:
  - Motion of object causes change of phase image
  - Difference of two phase images includes rigid-body and elastic displacement) information of object in terms of interferometric fringes "Interferogram"
  - Unwrapping and post processing of the interferograms
    separates rigid-body motion from elastic deformation part
    by best fit calculation for rigid-body part
- Accumulation of many successive interferograms results in total deformation map



ESPI optical path







Interferogram




# Part 3: STANT Thermo-Mechanical Deformation Test and Modeling





# **STANT TED Test Campaign**




STANT Antenna Reflector



# **Thermal Cycling and Thermo-Elastic Test**

- 3 in vacuo cycles from -120 C to +120 C
- TED-measurement of main reflector.
- Challenges
  - Any rigid-body motion must be limited in magnitude
  - Vibration isolation of the chamber
  - Thermal isolation of fixture from chamber
  - Window (spectral transmissibility for external sensor)
  - Reflector surface (optical contrast at reflector level)
  - Data processing
- Measurement via ESPI
- Results
  - No failure and low TED









# **Thermal Analysis**


- Correlation of thermal analysis and measured temperatures of TV cycling test
- Mapping of temperature results to structural model and analysis of corresponding deformations



Simulated temperatures on MR at end of cycle 1




Measured temperatures on MR at cycle 1



Simulated temperatures on MR at cycle 1




# **Initial Correlation**



**Qualitative comparison!** 




# **Validation Procedure**






# **Validation Procedure (STANT)**




Selection of region of interest to be used for image decomposition



# **Validation Procedure (STANT)**




Decomposition of ESPI UE=0.002



Decomposition of FEM UM=0.006



# **Validation Procedure (STANT)**



Ucal=0.003

UE=0.002

$$u(s_E) = \sqrt{u_{cal}^2(\varepsilon) + u_E^2}$$



# **Part 4: Conclusion and Outlook**



### **Conclusion**

#### **Model representation**

- Reflector deformation is sensitive to bonding layer
- Bonding layer varies across circumference of I/F
- Varying layer is not represented in model
- VANESSA method might help, e.g. in parametric analysis


#### **Region of interest**

- Test was not intended to be used for VANESSA methodology
- No complete test data (some regions missing)
- Orientation and alignment of test data not known
- Test data and FEM data input files don't match (size, maybe orientation, maybe alignment)
- ROI cannot be selected properly, best guess approach




# Outlook

- References on structure would help for ROI selection
- Alignment and orientation should be well known
- Representative/sufficient test data coverage
- Consider for VANESSA methodology during test planning and test activity










# Thank you for your attention.



MLI

**Instruments** Launcher and

Re-entry Components



**Radiators** 




**Structures** 



**Antennas** 



Reflectors



Deployable Structures

